## **SERVING THOSE** WHO PROTECT **FREEDOM**<sup>™</sup>



Made in the USA with US materials. If you have any comments, questions, or suggestions regarding our products, please contact us.

P.718.246.3838 F.718.246.3833 info@cryeprecision.com www.cryeprecision.com

©2016 Crye Precision LLC. AVS™, StKSS™, Crye Precision™ and the 'CP' logo are trademarks of Crye Precision LLC.



## FITTING/ADJUSTING VEST



O 1
Peel back outer cummerbund of CPC and insert StKSS extension into the lower pocket.



Insert StKSS<sup>™</sup> into corresponding pocket on Low Profile Belt<sup>™</sup> as shown.



05
Pull lanyard out to unlock. Lift buckle to lower StKSS extension.



UZ
Depress snap to secure into place.



 $04\,$  Pull down on lanyard to extend StKSS to desired length. Depress buckle to lock extension.



Optional: If you would like the StKSS™ to remain connected to the belt when the CPC is doffed, pass black strap through top row of MOLLE on belt and connect button.